AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION



767 SERIES

FLAMMABLE MATERIAL LOCATIONS

CAUTION: Rescue crews wearing full PPE to include SCBA's must use caution when moving across sections of aircraft that have been exposed to fatigue or fire as the result of an accident. Crews need to verify the integrity of the surface area before moving their weight and equipment across it. Signs could include but are not limited to deformity of structure, visual signs of flame impingement or uneven surfaces. Surface integrity can be checked with a pike pole, axe or any instrument used to sound surfaces for integrity. SURGE TANK APU HYDRAULIC ACCUMULATOR IN RIGHT WHEEL WELL HYDRAULIC RESERVOIR IN **RIGHT WHEEL WELL** FUEL TANK APU FUEL LINE 6070 GAL 22977 L DRY BAY **OPTIONAL PORTABLE OXYGEN BOTTLES** THROUGHOUT CABIN FUEL TANK OPTIONAL PORTABLE OXYGEN BOTTLES ON 1 >SURGE TANK FORWARD SIDE OF BULKHEAD 6070 GAL - 22977 L APU EMERGENCY CONTROL PANEL FUEL TANK LOCATED ON THE NOSE GEAR CREW OXYGEN BOTTLE IN **RIGHT SIDE. E & E** COMPARTMENT HOT BRAKES Normal cooling: Move aircraft to a suitable location and allow brakes to cool on their own. Water mist: Can be deployed from turret or handline. Fans: Placing fans may place firefighters very close to the hazard zone. **ENGINE OIL TANK -**

CENTER FUEL TANK CAPACITIES		
MODEL	GALLONS	LITERS
STANDARD	4,560	17,261
-200 ER	8,310	31,457
-300 ER	12,000	45,425
-400 ER	12,000	45,425

FORWARD RIGHT OR WHEEL FIRE

Apply large amounts of water initially with turrets. Transition to handline application to continue and maintain a cooling effect.

Wheels are equipped with fusible plugs designed to melt and deflate the tire when the temperature is excessive.

WARNING: Approach landing gear trucks from forward or aft at a 45 degree angle when approaching hot brakes or fighting a wheel fire, as rims and tires may pose a fragmentation hazard.


Copyright $\ensuremath{\mathbb{C}}$ Boeing. See title page for details.

REAR LEFT SIDE OF

EACH ENGINE




1 ENTRY/SERVICE DOOR EXTERNAL HANDLE



TO OPEN DOOR:

 PUSH IN DISARM LEVER (RED SURFACE LABLED "PUSH").
PULL AND LIFT OPERATING HANDLE TO UNLATCH DOOR.
MOVE DOOR UPWARD.

2 OVERWING ESCAPE HATCHES




TO OPEN HATCH:

- 1. LIFT LOWER PORTION OF HANDLE AWAY
- FROM THE SIDE OF THE AIRPLANE.
- 2. PUSH INWARD AND UP ON THE HANDLE. 3. PUSH HATCH INWARD.

EMERGENCY RESCUE ACCESS-1

3 TYPE 1 EMERGENCY EXIT DOOR



TO OPEN DOOR:

- 1. PUSH ON "PUSH" PANEL TO GAIN ACCESS TO HANDLE. 2. PULL HANDLE FORWARD AND OUTWARD. 3. DOOR OPENS OUTWARD AND DOWN.
- WARNING: STAND TO THE SIDE OF DOOR WHEN PULLING HANDLE. ESCAPE SLIDE DOES NOT DISARM AND WILL DEPLOY IMMEDIATELY WHEN A TYPE 1 DOOR IS OPENED FROM THE OUTSIDE.

4 CUT-IN AREAS

NOTE: CUT-IN AREAS REQUIRE METAL CUTTING PORTABLE POWER EQUIPMENT. BECAUSE OF TYPE OF STRUCTURE AND POSSIBLE INJURY TO PERSONNEL WITHIN, IT IS RECOMMENDED THAT MAJOR EFFORT TO GAIN ACCESS BE DIRECTED TO HATCHES AND DOORS. URGENCY OF SITUATION WILL DICTATE THE NECESSITY FOR A CUT-IN.

NOTES:

1. FOR ENTRY/SERVICE DOORS AND OVERWING HATCHES, ESCAPE SLIDE DISARMS AUTOMATICALLY WHEN DOOR OR HATCH IS OPENED FROM THE OUTSIDE.


2. ON PASSENGER AIRPLANES, COCKPIT WINDOWS CANNOT BE OPENED FROM THE OUTSIDE.

3. ON 767 FREIGHTERS, THE RIGHT SIDE COCKPIT WINDOW CAN BE OPENED FROM THE OUTSIDE.



767 SERIES


EMERGENCY RESCUE ACCESS-2



Copyright © Boeing. See title page for details.




BATTERY LOCATIONS






767 SERIES

FLIGHT DECK CONTROL SWITCH LOCATIONS





COMPOSITE MATERIALS LOCATIONS




Copyright © Boeing. See title page for details.



767 SERIES

PASSENGER SEATBELT AIRBAGS

Passenger Seatbelt Airbags



AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION



Intentionally Blank

Copyright © Boeing. See title page for details.