


#### **DC-7 SERIES**

# FLAMMABLE MATERIAL LOCATIONS




Copyright  $\ensuremath{\mathbb{C}}$  Boeing. See title page for details.




#### **EMERGENCY RESCUE ACCESS**

1 CREW AND MAIN CABIN DOORS EXTERNAL HANDLE




2 EMERGENCY EXIT DOORS EXTERNAL HANDLE




TO OPEN DOOR: 1. ROTATE HANDLE COUNTERCLOCKWISE. 2. PULL DOOR OUTWARD.

TO OPEN DOOR: 1. PULL HANDLE OUT. 2. PUSH DOOR INWARD. **3 ESCAPE HATCH EXTERNAL HANDLE** 



TO OPEN HATCH: 1. PULL HANDLE OUT. 2. ROTATE HANDLE COUNTERCLOCKWISE. 3. PULL HATCH OUT.

#### **4 CUT-IN AREAS**




NOTE: CUT-IN AREAS REQUIRE METAL CUTTING PORTABLE POWER EQUIPMENT. BECAUSE OF TYPE OF STRUCTURE AND POSSIBLE INJURY TO PERSONNEL WITHIN, IT IS RECOMMENDED THAT MAJOR EFFORT TO GAIN ACCESS BE DIRECTED TO HATCHES AND DOORS. URGENCY OF SITUATION WILL DICTATE THE NECESSITY FOR A CUT-IN.




#### **DC-7 SERIES**

#### **EMERGENCY RESCUE ACCESS**





#### **BATTERY LOCATIONS**






# **DC-7 FREIGHTER SERIES**

# FLAMMABLE MATERIAL LOCATIONS

WARNING: Approach landing gear trucks from forward or aft at a 45 degree angle when approaching hot brakes or fighting a wheel fire, as rims and tires may pose a fragmentation hazard.



Fans: Placing fans may place firefighters very close to the hazard zone.

#### WHEEL FIRE

Apply large amounts of water initially with turrets. Transition to handline application to continue and maintain a cooling effect.

Wheels are equipped with fusible plugs designed to melt and deflate the tire when the temperature is excessive.

CAUTION: Rescue crews wearing full PPE to include SCBA's must use caution when moving across sections of aircraft that have been exposed to fatigue or fire as the result of an accident. Crews need to verify the integrity of the surface area before moving their weight and equipment across it. Signs could include but are not limited to deformity of structure, visual signs of flame impingement or uneven surfaces. Surface integrity can be checked with a pike pole, axe or any instrument used to sound surfaces for integrity.




# **DC-7 FREIGHTER SERIES**

# **EMERGENCY RESCUE ACCESS-1**


**3 ESCAPE HATCH EXTERNAL HANDLE** 

1 CREW AND MAIN CABIN DOORS EXTERNAL HANDLE



**1. ROTATE HANDLE COUNTERCLOCKWISE.** 

2 EMERGENCY EXIT DOORS EXTERNAL HANDLE




TO OPEN DOOR: 1. PULL HANDLE OUT. 2. PUSH DOOR INWARD. TO OPEN HATCH: 1. PULL HANDLE OUT. 2. ROTATE HANDLE COUNTERCLOCKWISE. 3. PULL HATCH OUT.

#### **4 CUT-IN AREAS**

TO OPEN DOOR:

2. PULL DOOR OUTWARD.




NOTE: CUT-IN AREAS REQUIRE METAL CUTTING PORTABLE POWER EQUIPMENT. BECAUSE OF TYPE OF STRUCTURE AND POSSIBLE INJURY TO PERSONNEL WITHIN, IT IS RECOMMENDED THAT MAJOR EFFORT TO GAIN ACCESS BE DIRECTED TO HATCHES AND DOORS. URGENCY OF SITUATION WILL DICTATE THE NECESSITY FOR A CUT-IN.



# **DC-7 FREIGHTER SERIES**

# **EMERGENCY RESCUE ACCESS-2**



AIRPLANE RESCUE AND FIRE FIGHTING INFORMATION



AIRPLA DC-7 FREIGHTER SERIES

**Intentionally Blank** 

Copyright © Boeing. See title page for details.